

Alarm Troubleshooting Summary For Hirt VCS 100 Processor

Hirt VCS 100 Troubleshooting Summary				
VCS 100 Indicator Panel	Category	Light	Cause	Recommended Troubleshooting
OVERPRESSURE LIGHT	VCS 100 Processor or System	Red	UST ullage pressure is positive for at least 1 continuous hour.	<p>GDF Owner/Operator Responsibilities:</p> <ul style="list-style-type: none"> • “Daily Inspections” of Hanging Hardware as specified in section 6 of Installation, Operation, and Maintenance Manual. • “Drive-Offs and Other Customer Abuse” as specified in section 9 of Installation, Operation, and Maintenance Manual. • Exhibit 7 of Executive Order VR-205 • Record findings in GDF Owner/Operator Maintenance Log. <p>Certified Contractor Responsibilities:</p> <ul style="list-style-type: none"> • Follow VCS 100 Troubleshooting Guide (Contact Hirt by either Phone: (562) 692-6970 or by email: HirtVCS@aol.com to get Guide) • TP-201.3 and Exhibit 4 of Executive Order VR-205 • Exhibit 7 of Executive Order VR-205 • Exhibit 8 of Executive Order VR-205 • Record findings in GDF Owner/Operator Maintenance Log.